

STG Input / Output
AUX_0 OUT - Test Sensors

FEM0 Input / Output
AUX02IN - SIO
AUX03IN - SIS

